

CS1108

User's Manual



PWM Motor Controller

Document Number: DOC0000466A

Revision: B



WWW.CONTROLS.COM

2520 DIEHL ROAD • AURORA, ILLINOIS 60502 • PHONE: (630) 806-7062 • FAX: (630) 806-7065

Warranty

For warranty information please refer to the following website: <http://www.controls.com/index.php/support/warranty>

Disclaimer

Control Solutions LLC reserves the right to update this manual at any time without notice. This manual supersedes all previous issues, which must no longer be used. Control Solutions LLC reserves the right to change this product without any notification.

Control Solutions LLC and the Control Solutions logo are trademarks of Control Solutions LLC.

All other brand and product names, company names, and logos are trademarks or registered trademarks of their respective companies.

All materials contained within this manual, in printed or electronic format, are protected by copyright laws and other intellectual property laws.

© Copyright 2010-2011 Control Solutions LLC, Aurora, Illinois, USA. All rights reserved.

Control Solutions LLC
2520 Diehl Road
Aurora, Illinois 60502
Tel: (630) 806-7062
Fax: (630) 806-7065
Web: www.controls.com

Table of Contents	Page
Warranty	2
Disclaimer	2
Introduction	7
Purpose	7
Scope	7
Revision History	7
Precautions	7
Terms	8
Definitions	8
References	8
Audience	8
Product Description	9
Overview	9
Features	9
Specifications	10
Safety	11
Installation	13
Mounting	13
With Enclosure	13
Without Enclosure	14
Connectors	15
Pin out Definitions	16
RJ45 Connector (JP1)	16
18-pin Molex Mini-Fit Jr. (J7)	17
Battery Connections	18
4-pin Mini-Fit Jr. Connector (JP2)	18
Motor Connections	19
Wiring Diagrams	20
Throttle Wiring	20
Key Switch Wiring	22
Drive Mode Selector Switch Wiring	22
Quickstop Switch Wiring	23
Brake Release Switch Wiring	24
Forward/Reverse Switch Wiring	24

Controller Setup	25
Setting up the Throttle	26
Adjusting Throttle Deadband	26
Adjusting Throttle Scale	29
Adjusting Throttle Failband.....	31
Performance Parameters.....	32
Setting Maximum Speed	32
Acceleration and Deceleration.....	32
Programming the CS1108 PWM Motor Controller.....	35
CS1171 Hand-Held Programmer	35
Unit Layout.....	35
Display	35
Input and Navigation	36
Cable Interface	36
Connecting the HHP to the CS1108 PWM Motor Controller	37
Using the Hand-Held Programmer	37
Menus and Parameters	39
Main Menu.....	40
Indoor Mode Sub-Menu (Drive Mode 2)	47
Meters Sub-Menu.....	49
Advanced Sub-Menu.....	50
Options Sub-Menu	53
Functions Sub-Menu	56
Debug Sub-Menu	58
Parameter Information	63
Troubleshooting and Diagnostics.....	69
Contacting Customer Service	71
Parameter Setting Worksheet.....	73
Appendix A	75

List of Tables	Page
Table 1 - <i>Abbreviations and Acronyms</i>	8
Table 2 - <i>Reference Documentation</i>	8
Table 3 - <i>CS1108 Product Specifications</i>	10
Table 4 - <i>Motor Controller Connections</i>	15
Table 5 - <i>RJ45 Pin Cross Reference</i>	16
Table 6 - <i>Molex 18-pin Mini-Fit Jr. Cross Reference</i>	18
Table 7 - <i>Battery Pin Cross Reference</i>	18
Table 8 - <i>4-pin Mini-Fit Jr. Cross Reference</i>	19
Table 9 - <i>Motor Pin Cross Reference</i>	19
Table 10 - <i>HHP Navigation</i>	36
Table 11 - <i>HHP Main Menu Parameter Reference</i>	64
Table 12 - <i>HHP Indoor Mode Sub-menu Parameter Reference</i>	64
Table 13 - <i>HHP Meters Sub-menu Parameter Reference</i>	64
Table 14 - <i>HHP Advanced Sub-menu Parameter Reference</i>	65
Table 15 - <i>HHP Options Sub-menu Parameter Reference</i>	66
Table 16 - <i>HHP Functions Sub-menu Parameter Reference</i>	67
Table 17 - <i>HHP Debug Sub-menu Parameter Reference</i>	68
Table 18 - <i>Troubleshooting URLs</i>	69

List of Figures	Page
Figure 1 - <i>Precaution Blocks</i>	7
Figure 2 - <i>CS1108 PWM Motor Controller</i>	9
Figure 3 - <i>Mounting Dimensions with Enclosure</i>	13
Figure 4 - <i>Mounting Dimensions without Enclosure</i>	14
Figure 5 - <i>Motor Controller Connectors</i>	15
Figure 6 - <i>RJ45 Pin Layout</i>	16
Figure 7 - <i>Molex 18-pin Mini-Fit Jr. Connector</i>	17
Figure 8 - <i>Battery Pins</i>	18
Figure 9 - <i>4-pin Mini-Fit Jr. Connector</i>	18
Figure 10 - <i>Motor Connections</i>	19
Figure 11 - <i>Typical Application</i>	20
Figure 12 - <i>Standard Configuration Wiring</i>	20
Figure 13 - <i>Maximum/Minimum Application Wiring</i>	21
Figure 14 - <i>ANIN Max/Min Application Wiring</i>	21
Figure 15 - <i>Key Switch Wiring Options</i>	22
Figure 16 - <i>Drive Mode Wiring</i>	22
Figure 17 - <i>Quickstop Switch Wiring</i>	23

Figure 18 - Break Release Wiring.....	24
Figure 19 - Forward/Reverse Wiring	24
Figure 20 - Throttle Deadband, Scale and Failband	26
Figure 21 - HHP Front.....	35
Figure 22 - HHP Back.....	36
Figure 23 - HHP Connection to CS1108	37
Figure 24 - Menus and Parameters	39
Figure 25 - Throttle Scale.....	42
Figure 26 - Throttle Deadband.....	42
Figure 27 - Throttle Failband	43
Figure 28 - Ramp Shape Curve.....	44
Figure 29 - Current Parameter Relationships	45
Figure 30 - Charging Time Conversion	61

Introduction

Before using the CS1108 PWM Motor Controller please read this entire manual carefully to become familiar with the features, benefits and operation.

Purpose

This manual is intended to provide the information you will need to understand, connect and successfully configure the CS1108 PWM Motor Controller.

Scope

This manual explains the CS1108 PWM Motor Controller functions, parameters and usage. It also provides general care and maintenance as well as basic troubleshooting references.

Revision History

Revision	Update
B	Updated to clarify pin usage and pin definitions. Updated select Hand-Held Programmer parameter descriptions.

Precautions

This document contains hazard statements for your safety. Hazard statements are provided where safety consequences to personnel, equipment, and operation may exist. Failure to follow these statements may result in serious consequences.

A standard set of icons are used to draw your attention to the appropriate type of statement. Refer to Figure 1 for a partial sample of icons and statements.



Warning

A warning statement indicates the presence of a hazard that can cause severe injury or death.



Caution

A caution statement indicates the presence of a hazard that can or will cause minor injury or property damage.



This symbol is used whenever there is relevant supplemental information.

Figure 1 - Precaution Blocks

Terms

Table 1 defines the abbreviations and acronyms used in this document.

Abbreviation – Acronym	Definition
ASIC	Application Specific Integrated Circuit
CSLLC	Control Solutions Limited Liability Company
EM	Electromagnetic
GND	Ground
HHP	Hand-Held Programmer
kg	Kilogram
LCD	Liquid Crystal Display
LED	Light Emitting Diode
PCB	Printed Circuit Board
POD	Power on Demand
PWM	Pulse Width Modulation
RJ	Registered Jack

Table 1 - Abbreviations and Acronyms

Definitions

None

References

Table 2 lists related documentation.

Document Number	Title
000434A	CS1171C Hand-Held Programmer Instruction Manual OEM

Table 2 - Reference Documentation

Audience

This document was prepared for individuals that use the CS1108 PWM Motor Controller or technicians performing maintenance.

Product Description

This section of the document provides an overview of the CS1108 PWM Motor Controller, supported features and specifications.

Overview

The CS1108 PWM Motor Controller is a fully-programmable microprocessor-controlled medium to heavy-duty permanent magnet motor controller. The CS1108 PWM Motor Controller is ideal for use on three or four wheeled mobility scooters, as well as light industrial and commercial applications such as sweepers, scrubbers, and utility carts. The CS1108 offers the highest in current carrying capability of any motor controller its size in the industry today (up to 150 Amps peak) and is available in 12, 24, and 36 Volt models. The CS1108 uses industry standard connectors which allows for simple change over on existing product lines and field replacements. See Figure 2.



Figure 2 - CS1108 PWM Motor Controller

Features

The CS1108 PWM Motor Controller includes the following features:

- Four quadrant, full H-bridge design
- Fully Programmable
- Designed and 100% manufactured in the U.S.
- Designed to comply with U.S. and European regulations
- LED diagnostic codes
- Power on Demand - The Controller outputs the current necessary to instantly overcome obstacles such as ramps, curbs, and etc.
- Anti-Rollback - Virtually no roll back when stopping on inclines
- ASIC Technology - Our own custom mixed signal ASIC enables us to have decreased component count which results in increased reliability

- UL recognized component
- Programmable Power Saving Timeout
- Multiple drive modes
- Anti-jolt on power down
- On-board integrated charging control
- Throttle fault detection
- Low/high voltage shutdown
- Over temperature protection
- High pedal disable
- Power-up Diagnostics (brake/motor/etc.)

Specifications

Table 3 lists CS1108 PWM Motor Controller product specifications.

CS1108 Specifications	Minimum	Typical	Maximum	Units
Input Voltage – 12Vdc	8.5	12	20	Volts
Input Voltage – 24Vdc	17	24	36	Volts
Input Voltage – 36Vdc	26	36	48	Volts
Peak Current Limit*	-	150/110**	-	Amps
Continuous Current Limit*	-	70/40**	-	Amps
EM Brake Output Current	-	-	1.0	Amps
Key Switch Surge Current	-	2.0	4.0	mAmps
Continuous Key Switch Current	-	1.5	2.0	mAmps
Standby Current @ 24V	-	30	-	mAmps
Inactivity Timeout Current @ 24V	-	-	<1.0	mAmps
Operating Ambient Temperature	-40	25	45	°C
Extended Ambient Temperature (available on request)	-40	25	60	°C
Enclosure Flammability Rating	-	-	-	UL94V-0
Physical Size	-	3.3 x 5.8 x 1.8	-	Inches
Weight	-	0.37	-	kg

Specifications are subject to change without notice.

Table 3 - CS1108 Product Specifications

* These parameters are programmable.

** Depends on build option. The CS1108 is available in 150A peak and 110A peak versions.

Safety

Working with electric vehicles and batteries can be potentially dangerous. Proper precautions should be taken when setting up an electric vehicle or when working with batteries.



Caution

Vehicle Runaways – Malfunctions or operating conditions can occur when working with electric vehicles that can cause them to run. When working with or setting up an electric powered vehicle, it is recommended that you support the vehicle in a safe manner with the drive wheels off the ground, or disconnect the motor wires.



Caution

Battery Arcs – Short circuiting the battery terminals or connections can cause an electric arc. Always disconnect the battery connections when installing or working with high current vehicle batteries. It is recommended that you use insulated tools and wear safety glasses when working with high power batteries.



Caution

Battery Precautions – Normal charging and discharging of lead acid batteries produces hydrogen gas, which is extremely flammable and explosive. Follow the battery manufacturer's safety precautions and recommendations, when working with lead acid batteries. Always wear safety glasses.

This page intentionally left blank

Installation


This section of the manual describes the inputs and outputs provided on the CS1108 and how to install and wire the CS1108 in various applications.

Mounting

The CS1108 PWM Motor Controller can be mounted with an enclosure or without an enclosure.

With Enclosure

The CS1108 is equipped with two mounting holes located at the corners of the enclosure (See Figure 3). The mounting hole diameter is 0.180 inches. The CS1108 can be oriented in any position, but it is recommended that it be positioned in a manner to keep them away from excessive dirt and moisture to prevent damage. Also, the installation location should have proper airflow to keep the ambient temperature below 45° C. It is recommended to use #6 screws at 0.5 foot pounds (six inch pounds) torque.



** On the CS1108S, the cover extends above the heat sink and is approximately 1.55"

Figure 3 - Mounting Dimensions with Enclosure

Without Enclosure

The CS1108 PCB is equipped with four mounting holes located at the corners (See Figure 4). The mounting hole diameter is 0.1875 inches. The CS1108 can be oriented in any position, but it is recommended that it be positioned in a manner to keep it away from excessive dirt and moisture to prevent damage. Also, the installation location should have proper airflow to keep the ambient temperature below 45° C. It is recommended to use #6 screws at 0.5 foot pounds (six inch pounds) torque.




Figure 4 - Mounting Dimensions without Enclosure

Connectors

Table 4 provides a list of the CS1108 PWM Motor Controller connectors.

Label	Connector Type	Connects the....
JP1	RJ45	Hand-Held Programmer, Deluxe Display, or Enhanced Deluxe Display
J7	18-pin Molex Mini-Fit Jr.	Brake, horn, LEDs, and other CS1108 controls
-	Battery	Battery positive and negative wires
JP2	4-pin Mini-Fit Jr.	Battery charger
-	Motor	Motor positive and negative wires

Table 4 - Motor Controller Connections

Figure 5 shows the location of connectors on the CS1108.




Figure 5 - Motor Controller Connectors



Refer to **Appendix A** for a summary of the connectors and pin outs.

Pin out Definitions

The following section provides a diagram and pin out definition for each connector on the CS1108 PWM Motor Controller.

RJ45 Connector (JP1)

Figure 6 show the pin numbering for the RJ45 connector and Table 5 provides pin to name and description cross reference.




Figure 6 - RJ45 Pin Layout

Pin	Name	Description
1	Protected Batt +	Current limited, polarity protected, high voltage output
2	Battery -	Negative Battery
3	Key switch	Input for key switch on/off control
4	Clock	Used by Programmer and other intelligent devices
5	Data	Used by Programmer and other intelligent devices
6	Pot Low	Connects to the throttle potentiometer
7	Pot Wiper	Connects to the wiper on the throttle potentiometer
8	Pot High	Connects to the throttle potentiometer

Table 5 - RJ45 Pin Cross Reference

18-pin Molex Mini-Fit Jr. (J7)

Figure 7 shows the pin numbering of the Molex 18-pin Mini-Fit Jr. connector and Table 6 provides a pin to name and description cross reference.




Figure 7 - Molex 18-pin Mini-Fit Jr. Connector

Pin	Name	Description
1	Battery –	Use this pin for logic circuits or a battery charger
2	Battery –	Use this pin for logic circuits or a battery charger
3	Pot High	Connects to throttle potentiometer
4	Pot Wiper	Connects to the wiper on the throttle potentiometer
5	Key switch	Key switch input to turn on/off power
6	Brake	Negative output for an electromagnetic brake (Brake -)
7	Brake Release	Used for manual brake release
8	Indoor/Outdoor	An input for drive mode switch (Indoor = Drive mode 1, Outdoor = Drive mode 2)
9	LED	Output for Status LED
10	Battery +	Use this pin for logic circuits or a battery charger
11	See note 1	Refer to note 1
12	Quick Stop	Input for safety stop/inhibit
13	Pot Low	Connects to the throttle potentiometer
14	BB+	Positive output for an electromagnetic brake (Brake +)
15	Data	Used by Hand-Held programmer
16	Horn	Output for a horn
17	FWD/RVS	Input for forward/reverse switch
18	ANIN	Input for speed limit potentiometer (0-5V)
Note1: This pin is battery + on older versions of CS1108's and protected battery + (RAW24VH) on newer versions of CS1108's. Please contact CSLLC to verify pin 11 functionality for your CS1108.		

Table 6 - Molex 18-pin Mini-Fit Jr. Cross Reference

Battery Connections

Figure 8 shows the battery pin numbering and Table 7 provides a pin to name and description cross reference.




Figure 8 - Battery Pins

Pin	Name	Description
J1	Batt -	*Connected to the negative side of the battery(s)
J2	Batt +	Connected to the positive side of the battery(s)
J8	Batt +	*Connected to the positive side of the battery(s)
J9	Batt -	Connected to the negative side of the battery(s)
* Tabs J1 and J8 are only provided on select CS1108 models.		

Table 7 - Battery Pin Cross Reference

4-pin Mini-Fit Jr. Connector (JP2)

Figure 9 shows the 4-pin Mini-Fit Jr. pin numbering and Table 8 provides a pin to name and description cross reference.




Figure 9 - 4-pin Mini-Fit Jr. Connector

Pin	Name	Description
1	Charge Comm	Sets battery charge mode; low for bulk charge, high for float charge, no connection for off-board charger
2	Drive Inhibit	Inhibits drive during battery charging; when the battery is being charged the inhibit is high (5V)
3	Batt -	Negative Battery
4	Batt +	Positive Battery

Table 8 - 4-pin Mini-Fit Jr. Cross Reference

Motor Connections

Figure 10 shows the motor pin numbering and Table 9 provides a pin to name and description cross reference.




Figure 10 - Motor Connections

Pin	Name	Description
J3	M1 –	Connected to the negative terminal of the motor
J4	M1 –	Connected to the negative terminal of the motor
J5	M1 +	Connected to the positive terminal of the motor
J6	M1 +	Connected to the positive terminal of the motor

Table 9 - Motor Pin Cross Reference

Wiring Diagrams

Figure 11 shows a wiring diagram of a typical CS1108 PWM Motor Controller application.




Figure 11 - Typical Application

The remainder of this section depicts select wiring options and provides supporting text.

Throttle Wiring

A three-wire potentiometer throttle can be used to control the motor speed. Figure 12 shows how to wire a throttle potentiometer for a standard configuration.




Figure 12 - Standard Configuration Wiring

Figure 13 shows how to wire the throttle potentiometer when a max speed pot is used.




Figure 13 - Maximum/Minimum Application Wiring

Figure 14 shows how to wire the potentiometer when a max/min pot is used in conjunction with the ANIN signal on pin 18 of J7.



The controller must be specifically programmed for this configuration.




Figure 14 - ANIN Max/Min Application Wiring

Key Switch Wiring

Figure 15 shows two options to wire a key switch to the controller. When the switch is closed, the controller is powered **on**. When the switch is open, the controller is powered **off**. The value of **R** is 4.7k Ω .




Figure 15 - Key Switch Wiring Options

Using a red LED with a 4.7K Ω resistor, the above circuit would provide approximately 5 ma of current.

Drive Mode Selector Switch Wiring

Figure 16 shows how to wire a drive mode selector switch to the controller. The drive mode selector switches between Mode 1 and Mode 2 (which are also referred to as Indoor and Outdoor). These modes can be individually programmed to provide different max speeds, accelerations, etc. When the switch is open, the controller is in Drive Mode 1, when the switch is closed, the controller is in Drive Mode 2.




Figure 16 - Drive Mode Wiring

Quickstop Switch Wiring

Depending on the module configuration quickstop can be wired as active (+5 V) or passive (GND).

Figure 17 shows how to wire a passive quickstop configuration. When the switch is closed, quickstop is activated. When the switch is open, quickstop is inhibited.




Figure 17 - Quickstop Switch Wiring



In addition to the wired configuration there is a **Qstop hi** parameter (see the **Options** sub-menu on the HHP section of this document) that impacts quickstop activation. See the table below to properly configure the **Qstop hi** parameter with the external switch to disable the motor.

Qstop hi (on HHP)	External switch	Motor
On	Open	Disabled
Off	Closed	Disabled

Brake Release Switch Wiring

Figure 18 shows how to wire a brake release switch to the controller. The brake release switch is used to activate and deactivate an electronic brake mechanism. When the switch is closed, the brake is released. When the switch is open, the brake is activated.




Figure 18 - Break Release Wiring

Forward/Reverse Switch Wiring

Figure 19 shows how to wire a Forward/Reverse switch to the controller. The forward reverse switch will change the motors direction.




Figure 19 - Forward/Reverse Wiring

Controller Setup

This section of the manual provides instructions and guidelines on how to configure and program the most commonly used parameters of the CS1108 PWM Motor Controller. It includes instructions on setting up the throttle, and vehicle performance parameters.

Setting up the CS1108 PWM Motor Controller requires the use of a CS1171 Hand-Held Programmer. If you are not familiar with the CS1171 HHP, refer to section **CS1171 Hand-Held Programmer** that begins on page 35. That section includes general layout and navigation information as well as detailed information related to the various parameters.



Caution

Before performing the setup procedures, it is important that you support the vehicle on jacks or blocks to prevent the drive wheels from touching the ground and they can freely spin without obstruction. Doing so will prevent unattended dangerous vehicle movement.

Double check all wiring to ensure there are no shorts and that everything is properly wired per the Wiring Diagrams in the **Installation** section of this manual.

Be sure to wear proper eye protection in case of lead acid battery failure.



Important

Before performing the following procedures, make sure that no error codes are present on the Hand-Held programmer. For information on error codes, see **Troubleshooting and Diagnostics**, on page 69 of this manual.

Setting up the Throttle

Properly setting up the throttle on a vehicle will ensure that you obtain peak performance and control of speed on the vehicle. The steps involved in setting up the throttle are:

1. Adjusting the throttle deadband,
2. Adjusting the throttle scale, and
3. Adjusting the throttle failband.

You should perform these procedures in the order they appear in this manual. When done properly, the vehicle will perform smoothly throughout the entire throttle range and provide the highest resolution of throttle control. Figure 20 shows the Throttle Deadband, Throttle Scale, and Throttle Failband for Unidirectional and Bidirectional Throttles.




Figure 20 - Throttle Deadband, Scale and Failband

Adjusting Throttle Deadband

The first step in setting up the throttle is adjusting the Throttle Deadband. Throttle Deadband sets the range of the neutral zone in the throttle input. To adjust the Throttle Deadband, use the following procedure:

1. Securely prop the drive wheels of the vehicle off the ground using jacks or some form of stand. Make sure it is secure so the vehicle will not fall off the stands. Ensure there are no obstructions touching the drive wheels and that they can rotate freely.
2. Verify that the throttle mechanism is in the neutral position.
3. Connect the CS1171 Hand-Held Programmer to **JP1** on the CS1108 PWM Motor Controller. (See Figure 23)



Depending on the interface configuration to the CS1108, it may be necessary to use the CS1303 Y-adapter to bridge the display unit and the CS1171 to JP1 on the CS1108. For additional information see the documentation included with CS1171 Hand-Held Programmer.

4. Turn on vehicle power (this will power up the CS1171).

5. Verify that no error codes are displayed on the CS1171 Hand-Held Programmer display. If error codes are displayed, refer to **Troubleshooting and Diagnostics** on page 69 of this manual for information about clearing the errors.
6. If there is a potentiometer that sets the maximum speed on the vehicle, make sure it is adjusted to the maximum $\cup$ speed setting.
7. If an Unidirectional throttle is used, follow the steps below:

Step	Action
1	On the HHP from the Main menu, scroll down to the Options > menu parameter
2	Press > to enter the Options menu
3	Scroll down to the Unidir thrt parameter
4	Press > to select the parameter
5	Press + until the parameter is set to On
6	Press < to set the value
7	Scroll down to the 0V tht neut parameter
8	Press > to select the parameter
9	Press + until the parameter is set to On
10	Press < to set the value

8. If a Bidirectional throttle is used, follow the steps below:

Step	Action
1	On the HHP from the Main menu, scroll down to the Options > menu parameter
2	Press > to enter the Options menu
3	Scroll down to the 0V tht neut parameter
4	Press > to select the parameter
5	Press + until the parameter is set to Off
6	Press < to set the value
7	Scroll up to the Unidir thrt parameter
8	Press > to select the parameter
9	Press + until the parameter is set to Off which sets the bidirectional throttle to drive the vehicle forward in one direction, and in reverse the other direction Set the parameter to On to set the bidirectional throttle to drive the vehicle in the same direction no matter which way the bidirectional throttle is actuated
10	Press < to set the value

9. If the throttle has a mechanical adjustment, follow the steps below:

Step	Action
1	On the HHP from the Main menu, scroll down to the Debug > menu parameter
2	Press > to enter the Debug menu
3	Scroll down to the Throt val parameter
4	Is the parameter value 0%? • If yes, continue with step 6 • If no, continue with step 5
5	Adjust the throttle until the desired parameter value is displayed  Refer to the product documentation for specifics related to the physical throttle adjustments.
6	You have completed the throttle adjustment; continue with the step below this table.

10. Select **Deadband** in the Main Menu of the CS1171 Hand-Held Programmer. Set the value to **0**.
11. Move the vehicle's throttle to the position where you want the vehicle to start moving. It is recommended that the throttle position not be too far from the neutral position.
12. While holding the throttle in the position where you want it to engage, adjust the value of **Deadband** up until you hear the relays click on the controller.
13. Release the throttle mechanism.
14. Throttle Deadband setup is complete.

Adjusting Throttle Scale

The throttle scale value determines the throttle potentiometer voltage required for full speed. Under adjusting the throttle scale will result in failure to reach full speed. Over adjusting the throttle scale will result in reaching full speed too soon, and a reduction of speed control. To adjust the throttle scale, use the following procedure:

1. If there is a potentiometer that sets the maximum speed on the vehicle, make sure it is adjusted to the maximum $\cup$ speed setting.
2. After properly adjusting the Throttle Deadband, select **Throtl scl** in the Main Menu of the Hand-Held Programmer.
3. Adjust the value of **Throtl scl** such that you just arrive at a **Throt val** of **100%** at the full deflection of the throttle mechanism. Follow the steps below:

Step	Action
1	On the HHP Main menu, scroll down to the Throt scl parameter
2	Press > to select the parameter
3	Press – until the Throt scl is a value of 1
4	Press the < button to set the value
5	Scroll down to the Debug > menu parameter
6	Press > to select the Debug menu
7	Scroll down to the Throt val parameter
9	Fully depress the throttle mechanism
10	Monitor the Throt val parameter, it should be 100% at full throttle
11	Is the Throt val 100% at full throttle? • If yes, continue with step 19 • If no, continue with the next step
12	Scroll up to the < Main menu parameter
13	Press < to enter the main menu
14	Scroll up to the Throtl scl parameter
15	Press > to select the parameter
16	Press + once to increment Throt scl by one (the range is 0-255)
17	Press the < button to set the value
18	Return to step 5 of this table
19	If using a bidirectional throttle, have both directions of the throttle been calibrated? • If yes, you are finished adjusting the throttle scale • If no, repeat steps 5-19 for the other side of the throttle



To compensate for mechanical tolerance and ensure that **Throt val** always reaches 100%, **Throt scl** should be padded by a value of 1 or 2. This will cause the **Throt val** to reach 100% just shy of the nominal mechanical limit. In addition to compensating for mechanical tolerance, padding the **Throt scl** helps ensure constant full speed when the user has to hold the throttle at the maximum position for extended periods. Without the padding, the user may experience speed fluctuations as their grip relaxes on the throttle slightly over time.

The padded **Throt scl** value should be experimented with to achieve desired results. The results of padding the **Throt scl** value can be seen in Figure 20 between Full Speed and Mechanical Limit where PWM is 100%. If no padding were implemented, Full Speed and Mechanical limit would be one in the same.

4. Throttle Scale setup is complete.

Adjusting Throttle Failband

The Throttle Failband is an area beyond the full speed throttle voltage that disables the motor. Throttle Failband provides a safety feature to protect against throttle shorts or open circuits, which could lead to undesired movement of the vehicle.



Perform this procedure **only after** properly adjusting the Throttle Deadband and Throttle Scale.

To adjust the Throttle Failband, use the following procedure:

- 1. If there is a potentiometer that sets the maximum speed on the vehicle, make sure it is adjusted to the maximum  speed setting.

Step	Action
1	On the HHP Main menu, scroll down to the Failband parameter
2	Press > to select the parameter
3	Press + until the highest value is reached (255) - this disables Failband
4	Press < to set the value
5	Actuate the throttle mechanism on the vehicle to the full mechanical limit
6	While still on the Failband parameter, press > to select the parameter
7	Press – one click per second until the motor stops
8	Press + until the value of Failband is increased by 10

This completes setting up the throttle.

Performance Parameters

The CS1108 PWM Motor Controller contains parameters that control many performance characteristics of how a vehicle will perform. Using these parameters allows the controller to be programmed for a wide variety of applications. After setting up the throttle it is recommended that you set up the maximum speed and acceleration/deceleration characteristics of the vehicle.

Setting Maximum Speed

The CS1108 PWM Motor Controller allows you to configure separate maximum speeds for forward and reverse directions. The **FWD speed** and **RVS speed** parameters set the percentage of maximum speed allowed to the motor when the throttle is in the full position, and the speed adjustment potentiometer (if used) is set to full. To adjust the maximum speeds:

1. If your vehicle is equipped with a speed adjustment potentiometer, turn it to its maximum setting.
2. Ensure the Hand-Held Programmer is connected to the CS1108 PWM Motor Controller and the vehicle is powered up.
3. Drive the vehicle forward and adjust the **FWD speed** parameter in the Main menu until the vehicle travels at the desired maximum speed at full throttle.
4. Place the vehicle in reverse.
5. Drive the vehicle backwards and adjust the **RVS speed** parameter in the Main menu until the vehicle travels at the desired maximum speed at full throttle.

Acceleration and Deceleration

The acceleration and deceleration parameters give you control of how smooth the vehicle accelerates and decelerates. Fast acceleration and deceleration rates will give the vehicle quick performance but will discharge the batteries at a higher rate.

Setting Forward Acceleration and Deceleration

To adjust the Forward Acceleration and Deceleration, follow this procedure:

1. If your vehicle is equipped with a speed adjustment potentiometer, turn it to its maximum setting.
2. Ensure the Hand-Held Programmer is connected to the CS1108 PWM Motor Controller and the vehicle is powered up.
3. From a stopped position, press the throttle to the full throttle position to check the acceleration rate.
4. Adjust the **FWD accel** parameter in the Main menu until the vehicle accelerates smoothly at the desired rate.
5. After you have adjusted the forward acceleration rate, drive the vehicle forward at full throttle.
6. Release the throttle and observe how fast the vehicle decelerates to a stop. Adjust the **FWD decel** parameter in the Main menu until the vehicle decelerates smoothly at the desired level.

Setting Reverse Acceleration and Deceleration

To adjust the Reverse Acceleration and Deceleration, follow this procedure:

1. If your vehicle is equipped with a speed adjustment potentiometer, turn it to its maximum setting.
2. Ensure the Hand-Held Programmer is connected to the CS1108 PWM Motor Controller and the vehicle is powered up.
3. Place the vehicle in reverse and make sure there are no hazards behind the vehicle.
4. From a stopped position, press the throttle to the full throttle position to check the reverse acceleration rate.
5. Adjust the **RVS accel** parameter in the Main menu until the vehicle accelerates smoothly in reverse at the desired rate.
6. After you have adjusted the reverse acceleration rate, drive the vehicle in reverse at full throttle.
7. Release the throttle and observe how fast the vehicle decelerates to a stop. Adjust the **RVS decel** parameter in the Main menu until the vehicle decelerates smoothly at the desired level.

You should now have a properly configured vehicle.

This page intentionally left blank

Programming the CS1108 PWM Motor Controller

The CS1108 PWM Motor Controller is equipped with an RJ45 connector (JP1) that can be used to connect a CS1171 Hand-Held programmer. The CS1171 Hand-Held Programmer allows total customization of the controller and its operating parameters.

CS1171 Hand-Held Programmer

Control Solutions' CS1171 Hand-Held Programmer was designed to offer field programmability to the end user, dealer, and distributor of CSLLC Programmable Motor Controllers, or products containing them. Providing flexibility of use, custom-tailored driving characteristics, debugging features, and many other special features to better match the performance of the product with the customer, the HHP serves as an invaluable tool.

Unit Layout

The programmer contains a Liquid Crystal Display (LCD) and five button keypad on the front of the unit, and one RJ45 port on the back. See Figure 21 and Figure 22.




Figure 21 - HHP Front

Display

Information is output to the user through the 16 character x 2 line LCD display located on the front of the unit.

Input and Navigation

The user can review and configure controllers by navigating through a series of menus and options. Navigation is performed using the keypad buttons on the front of the unit. Table 10 describes the function of each HHP keypad button.

Button	Meaning
	Currently this button only serves to power up or power down the unit. With most applications, the HHP will power up with the system.
	This button is used to navigate to the Main Menu or set a parameter.
	This button is used to scroll down through the menu list or decrement the current parameter.
	This button is used to scroll up through the menu list or increment the current parameter.
	This button is used to access a lower level menu or select a parameter to modify.

Table 10 - HHP Navigation

Cable Interface

The RJ45 port is located on the top middle back of the HHP unit. See Figure 22.



Figure 22 - HHP Back

Connecting the HHP to the CS1108 PWM Motor Controller

Figure 23 shows how to connect the CS1171 Hand-Held Programmer to the CS1108 PWM Motor Controller.




Figure 23 - HHP Connection to CS1108



Depending on the interface configuration to the CS1108, it may be necessary to use the CS1303 Y-adapter to bridge the display unit and the CS1171 to JP1 on the CS1108. For additional information see the documentation included with CS1171 Hand-Held Programmer.

Using the Hand-Held Programmer

Follow the directions below to prepare and use the CS1171 HHP.

1. Insert one end of the interface cable into HHP's 8-pin jack (RJ45).
2. With the controller turned **off**, connect the other end of the cable to the controller's **JP1** port.
3. Turn on the Hand-Held Programmer by pressing the **Power/Enter** button, or by turning on the CS1108 PWM Motor Controller using the key switch.
4. If the HHP is compatible with the controller version, upon powering up the HHP, a splash screen **CS Programmer CS1171C OEM Vxxx** (for the OEM version) or **CS Programmer CS1171R DLR Vxxx** (for the Dealer version) is displayed for five seconds, followed by the **Main menu**. If the controller generates a fault code, the first menu item will be the controller's fault code followed by **FWD speed**. If no fault code is present, the first menu item is **FWD speed**. Powering up the controller with a fault code will not inhibit HHP functionality.



If the controller version is incompatible with the HHP version, the HHP will display **BAD REV! See user manual** for three seconds, and then the controller firmware version will be displayed **FW rev h xxx FW I xxx**, and HHP functions will be disabled. (Refer to the **Contacting Customer Service** section of this manual for direction.)

5. To modify a parameter:

Step	Action
1	Scroll through the Main menu using + to scroll up, and – to scroll down, until the parameter you wish to change is reached ☞ When selected, the parameter will blink
2	Press > to select the parameter value
3	Press the + to increment/toggle the parameter or – to decrement/toggle the parameter value
4	Press < to save the value to the controller

As a parameter's value is modified, it is continuously updated to the controller so that its effect can be verified immediately. If power is lost to the controller or the HHP **Power/Enter** button is pressed before the parameter is saved, the parameter may revert back to its previous value. (Refer to **Menus and Parameters** and **Parameter Information** for details on specific parameters).



You can rapidly scroll through menu parameters or increment/decrement parameter values by pressing and holding the + or – buttons.

6. To enter a menu other than the **Main menu**:

Step	Action
1	Scroll through the Main menu using + to scroll up, and – to scroll down, to the sub-menu you wish to enter ☞ Sub-menus are easy to recognize by the > after the menu name When selected, the sub-menu name will blink
2	Press > to enter the sub-menu ☞ The first entry in all sub-menus is a return to the < Main menu item
3	Repeat the steps listed in the previous table to change a parameter within the sub-menu
4	Press + to scroll up to the < Main menu item
5	Press < to return to the Main menu

Refer to **Menus and Parameters** and **Parameter Information** for details on the specific menus.

7. When finished using your HHP, it can be turned off by:

- Pressing the **Power/Enter** button on the HHP,
- Disconnecting it from the controller or Y-Adapter, or
- Turning off the controller power.

Menus and Parameters




Figure 24 - Menus and Parameters



The above menu is from an "OEM" HHP. The descriptive information on the following pages can be used for both a Dealer and OEM HHP. See **Parameter Information** for parameter details.

Main Menu


Parameter	Description
FAULT CODE!	If the Hand-Held Programmer is powered up and the controller generates a fault code, the first menu item is the controller's fault code. When a fault code is displayed e.g. 12h, the > button can be pushed to momentarily display the text associated with the error code e.g. EM-brake Open. When no fault code is present, the first menu item will be FWD speed. Powering up the controller with a fault code will <u>not</u> inhibit Hand-Held Programmer functionality.
FWD speed	Sets the percentage of the maximum forward speed allowed to the motor when the throttle has reached the full forward position and speed control is set to full speed.
RVS speed	Sets the percentage of the maximum reverse speed allowed to the motor when the throttle has reached the full reverse position and speed control is set to full speed.
Min speed	Sets the minimum percentage of speed for forward/reverse throttle when the Enhanced Deluxe Display Pot or ANIN input is at its lowest setting. If set to 0, and Enhanced Deluxe Display Pot is turned all of the way down, the forward/reverse speed is 0.
FWD accel	Sets the amount of forward acceleration. The higher the percent value, the faster the forward acceleration.
FWD decel	Sets the amount of forward deceleration. The higher the percent value, the faster the forward deceleration.
FWD>RVSdcl	Sets the amount of forward deceleration during a forward-to-reverse direction change of throttle. The higher the percent value, the faster the forward deceleration during a forward-to-reverse direction change of the throttle.
RVS accel	Sets the amount of reverse acceleration. The higher the percent value, the faster the reverse acceleration.
RVS decel	Sets the amount of reverse deceleration. The higher the percent value, the faster the reverse deceleration.
RVS>FWDdcl	Sets the amount of reverse deceleration during a reverse-to-forward direction change of throttle. The higher the percent value, the faster the reverse deceleration during a reverse-to-forward direction change of the throttle.

Parameter	Description																
Motor comp	Sets the motor compensation which is the calibration value used to compensate speed control for varying terrain, also known as Power On Demand (POD). Set to 0 for no speed control compensation.  Warning Setting this parameter too high can result in an over compensated drive motor that may behave erratically. Please seek advice from your manufacturer or dealer before attempting to calibrate this parameter. This feature should typically only be used by the manufacturer. To calibrate: <table border="1"> <thead> <tr> <th>Step</th><th>Action</th></tr> </thead> <tbody> <tr> <td>1</td><td>Set Motor comp to 0</td></tr> <tr> <td>2</td><td>Set FWD speed to 50%</td></tr> <tr> <td>3</td><td>Drive at full throttle on flat terrain and measure vehicle speed</td></tr> <tr> <td>4</td><td>Drive at full throttle on a moderate incline and increase the Motor comp until the vehicle's speed matches the speed measurement in step 3</td></tr> <tr> <td>5</td><td>Verify that PWM is not 100% (monitor PWM in the Debug menu)</td></tr> <tr> <td>6</td><td>Is PWM is 100%? • If yes, reduce FWD speed and continue with step 3. • If no, continue with the next step </td></tr> <tr> <td>7</td><td>Reduce the Motor comp value by 20% to allow for temperature tolerance of the motor and controller</td></tr> </tbody> </table>	Step	Action	1	Set Motor comp to 0	2	Set FWD speed to 50%	3	Drive at full throttle on flat terrain and measure vehicle speed	4	Drive at full throttle on a moderate incline and increase the Motor comp until the vehicle's speed matches the speed measurement in step 3	5	Verify that PWM is not 100% (monitor PWM in the Debug menu)	6	Is PWM is 100% ? • If yes, reduce FWD speed and continue with step 3. • If no, continue with the next step	7	Reduce the Motor comp value by 20% to allow for temperature tolerance of the motor and controller
Step	Action																
1	Set Motor comp to 0																
2	Set FWD speed to 50%																
3	Drive at full throttle on flat terrain and measure vehicle speed																
4	Drive at full throttle on a moderate incline and increase the Motor comp until the vehicle's speed matches the speed measurement in step 3																
5	Verify that PWM is not 100% (monitor PWM in the Debug menu)																
6	Is PWM is 100% ? • If yes, reduce FWD speed and continue with step 3. • If no, continue with the next step																
7	Reduce the Motor comp value by 20% to allow for temperature tolerance of the motor and controller																
Indoor mode >	See Indoor Mode Sub-Menu on page 47. Indoor Mode is also referred to as Drive Mode 2.																

Parameter	Description
Throtl scl	Sets the throttle scale which determines the throttle pot voltage needed for full speed, and sets the amount of throttle movement necessary to obtain full throttle. See Figure 25. Unidirectional Throttle Bidirectional Throttle Figure 25 - Throttle Scale
Deadband	Sets the throttle pot range that the controller determines as neutral (See Figure 26). Unidirectional Throttle Bidirectional Throttle Figure 26 - Throttle Deadband

Parameter	Description
Failband	This is an area beyond the full speed throttle voltage that disables the motor (See Figure 27). Throttle Failband provides a safety feature to protect against throttle shorts to ground or 5V, which could lead to dangerous runaways. Unidirectional Throttle  Bidirectional Throttle  Figure 27 - Throttle Failband
Push speed	Sets a percentage of the maximum allowable speed (PWM) to manually move the unit by releasing the electromagnetic brake. Increasing the percentage makes the unit easier to push. To work properly, the following conditions must be met: • The key switch must be off • The EM brake must be manually released • Idle push set to off OR • The key switch on • The EM brake is manually released • The throttle is idle • Idle push is set to on
Hold time	Sets the spasticity control which is used to filter unwanted fast changes in throttle input, or to smooth out the throttle feel. Higher hold time results in a more relaxed and filtered throttle response range.

Parameter	Description
Ramp shape	Sets the shape of throttle curves. This value is used to determine the ratio of linear to logarithmic shape on the throttle curve. A higher ramp shape value results in a more progressive throttle response when changing throttle inputs. A setting higher than 3 will usually roll off low end throttle response too far and is not recommended. Figure 28 shows the ramp shape curve with the ramp shape settings of 0, 1, 2, and 3.
Comp rspns	Sets the Compensation Response in percent. A boost is progressively applied when surmounting obstacles such as inclines, doorway thresholds, bumps, etc. This boost is set by the parameter Motor comp. A higher value of Comp rspns results in a faster boost response time.
Brake time	Sets the nominal amount of time from when the motor PWM=0 until the EM Brake is de-energized. This prevents EM braking before a complete stop.
Keyoff dcl	Sets a filter constant for key switch off or active quickstop condition. The higher the percentage, the faster the deceleration when the key switch is turned off while driving, or quickstop is asserted.

Parameter	Description
Batt res	Sets the resistance of the power wires. It's used to compensate the battery display for wiring drop at high current. It is typically calculated in milliohms: Batt res value/3485.1485= Resistance in ohms
Timeout	The length of time before the controller powers down after inactivity. When set to 0, the controller will not timeout.
Flash V	Sets the point when the battery voltage reaches the desired low voltage threshold. When the battery voltage reaches the value set by Flash V, an LED is flashed. The Flash V value is in volts.
Full V	Sets the desired point when the battery voltage level is considered to be fully charged. When using a multi-segmented LED, this voltage value indicates a full battery on the display. Full V is displayed in Volts.
Cur lim lo	Sets the Current Limit Lower Bound, maximum current allowable (in Amps). After the Current Limit Upper Bound threshold time is exceeded (Cur time) the motor controller will limit the maximum current to this value which protects the motor and supporting components. Due to tolerances in the drive system, it is recommended to verify the current limit. See Figure 29.  Warning Setting the current limit value too high can result in damage to the motor controller, as well as other components in the vehicle. Do not set this value higher than the maximum rated current for the motors, cables, batteries, and controller. Refer to Table 11 for range values.  Figure 29 - Current Parameter Relationships

Parameter	Description														
Cur lim hi	Sets the Current Limit Upper Bound, maximum current allowable (in Amps). When initially current limiting, current will not exceed the upper bound. Due to tolerances in the drive system, it is recommended to verify the maximum current limit. See Figure 29. To verify the maximum current limit: <table> <tr> <th>Step</th><th>Action</th></tr> <tr> <td>1</td><td>Stall the drive motor</td></tr> <tr> <td>2</td><td>Apply full throttle to the controller and measure the motor current with a calibrated DC clamp meter</td></tr> <tr> <td>3</td><td> If the current is: - Too high, decrement the Cur lim hi parameter by one - Too low, increment the Cur lim hi parameter by one - Acceptable, continue with step 6 </td></tr> <tr> <td>4</td><td>Allow the controller to cool off for a minute or two</td></tr> <tr> <td>5</td><td>Go to step 1</td></tr> <tr> <td>6</td><td>Stop you have completed this procedure</td></tr> </table>  Warning Setting the current limit value too high can result in damage to the motor controller, as well as other components in the vehicle. Do not set this value higher than the maximum rated current for the motors, cables, batteries, and controller. Refer to Table 11 for range values.	Step	Action	1	Stall the drive motor	2	Apply full throttle to the controller and measure the motor current with a calibrated DC clamp meter	3	If the current is: - Too high, decrement the Cur lim hi parameter by one - Too low, increment the Cur lim hi parameter by one - Acceptable, continue with step 6	4	Allow the controller to cool off for a minute or two	5	Go to step 1	6	Stop you have completed this procedure
Step	Action														
1	Stall the drive motor														
2	Apply full throttle to the controller and measure the motor current with a calibrated DC clamp meter														
3	If the current is: - Too high, decrement the Cur lim hi parameter by one - Too low, increment the Cur lim hi parameter by one - Acceptable, continue with step 6														
4	Allow the controller to cool off for a minute or two														
5	Go to step 1														
6	Stop you have completed this procedure														
Cur time	Sets the delay time before a controller abruptly drops from the programmed maximum allowable current limit (Cur lim hi) to the lower current limit (Cur lim lo), when Step curlim is enabled. See Figure 29.														
Meters >	See Meters Sub-Menu on page 49.														
Advanced >	See Advanced Sub-Menu on page 50.														
Options >	See Options Sub-Menu on page 53.														
Functions >	See Functions Sub-Menu on page 56.														
Debug >	See Debug Sub-Menu on page 58.														
HHP Cntrst	Adjusts the Hand-Held Programmer's LCD contrast. 0 = lightest; 50 = default; 100 = darkest														

Indoor Mode Sub-Menu (Drive Mode 2)

The following Indoor Mode (Drive Mode 2) parameters will only be active if the controller's IN/OUT input is asserted (5V). If a controller does not have an IN/OUT input, these parameters are **not** used.

Parameter	Description
In FWD spd	Sets the percentage of the maximum indoor forward speed allowed to the motor when the throttle has reached the full forward position and speed control is set to full speed.
In RVS spd	Sets the percentage of the maximum indoor reverse speed allowed to the motor when the throttle has reached the full reverse position and speed control is set to full speed.
In FWD acl	Sets the amount of indoor forward acceleration. The higher the percent value, the faster the indoor forward acceleration.
In FWD dcl	Sets the amount of indoor forward deceleration. The higher the percent value, the faster the indoor forward deceleration.
In FWD dch	Sets the amount of indoor forward deceleration during a forward-to-reverse direction change of throttle. The higher the percent value, the faster the indoor forward deceleration during a forward-to-reverse direction change of the throttle.
In RVS acl	Sets the amount of indoor reverse acceleration. The higher the percent value, the faster the indoor reverse acceleration.
In RVS dcl	Sets the amount of indoor reverse deceleration. The higher the percent value, the faster the indoor reverse deceleration.
In RVS dch	Sets the amount of indoor reverse deceleration during a reverse-to-forward direction change of throttle. The higher the percent value, the faster the indoor reverse deceleration during a reverse-to-forward direction change of the throttle.

Parameter	Description																
In mot cmp	Sets the indoor motor compensation which is the calibration value used to compensate speed control for varying terrain, also known as Power On Demand (POD). Set to 0 for no speed control compensation. To calibrate: <table><tr><th>Step</th><th>Action</th></tr><tr><td>1</td><td>Set In mot cmp to 0</td></tr><tr><td>2</td><td>Set FWD spd to 50%</td></tr><tr><td>3</td><td>Drive at full throttle on flat terrain and measure vehicle speed</td></tr><tr><td>4</td><td>Drive at full throttle on a moderate incline and increase the In mot cmp until the vehicle's speed matches the speed measurement in step 3</td></tr><tr><td>5</td><td>Verify that PWM is not 100% (monitor PWM in the Debug menu)</td></tr><tr><td>6</td><td>Is PWM is 100%? • If yes, reduce FWD speed and continue with step 3 • If no, continue with the next step </td></tr><tr><td>7</td><td>Reduce the In mot cmp value by 20% to allow for temperature tolerance of the motor and controller</td></tr></table>  Setting this parameter too high can result in an over compensated drive motor that may behave erratically. Please seek advice from your manufacturer or dealer before attempting to calibrate this parameter. This feature should typically only be used by the manufacturer.	Step	Action	1	Set In mot cmp to 0	2	Set FWD spd to 50%	3	Drive at full throttle on flat terrain and measure vehicle speed	4	Drive at full throttle on a moderate incline and increase the In mot cmp until the vehicle's speed matches the speed measurement in step 3	5	Verify that PWM is not 100% (monitor PWM in the Debug menu)	6	Is PWM is 100% ? • If yes, reduce FWD speed and continue with step 3 • If no, continue with the next step	7	Reduce the In mot cmp value by 20% to allow for temperature tolerance of the motor and controller
Step	Action																
1	Set In mot cmp to 0																
2	Set FWD spd to 50%																
3	Drive at full throttle on flat terrain and measure vehicle speed																
4	Drive at full throttle on a moderate incline and increase the In mot cmp until the vehicle's speed matches the speed measurement in step 3																
5	Verify that PWM is not 100% (monitor PWM in the Debug menu)																
6	Is PWM is 100% ? • If yes, reduce FWD speed and continue with step 3 • If no, continue with the next step																
7	Reduce the In mot cmp value by 20% to allow for temperature tolerance of the motor and controller																

Meters Sub-Menu

The Meters Sub-Menu provides several useful entries that display various statistics.

Parameter	Description
Hours	Displays the number of hours the controller has been operated.
Low Batt	Displays the number of hours the unit has been operated with the battery voltage level below the low battery threshold.
Overtmps	Displays the number of over temperature conditions that have occurred.
Tht Faults	Displays the number of times a throttle failband failure occurred.
Chg Nofloats	Displays the number of times the charge cycle was ended early.



The above counts and timers do not roll over and cannot be cleared.

Advanced Sub-Menu

Parameter	Description
Fwd Plg Tm	The duration of time the motor is reversed after the quickstop input is activated while driving forward.
Rvs Plg Tm	The duration of time the motor is reversed after the quickstop input is activated while driving in reverse.
Regen off	Regenerative braking utilizes the fact that an electric motor can also act as a generator. The vehicle's motor is used as a generator during braking, conserving battery power. Setting this menu option to: • On, turns off regenerative braking • Off, turns on regenerative braking
Idle push	Idle push allows the unit to be manually pushed and limits the speed to a percentage defined by Push speed. To work properly, the following conditions must be met: • The key switch is on • The EM brake is manually released • The throttle is idle • Idle push is set to on
Creep spd	Sets drive mode 1 creep speed. It is the minimum PWM percentage applied to the motor output after the throttle exceeds Deadband. This setting helps prevent rollback on inclines when the brake releases with minimal throttle applied.  This setting should not be set too high to achieve proper low speed control on flat ground.
In CRP spd	Sets drive mode 2 creep speed. It is the minimum PWM percentage applied to the motor output after the throttle exceeds Deadband. This setting helps prevent rollback on inclines when the brake releases with minimal throttle applied and is active when IN/OUT input is asserted.  This setting should not be set too high to achieve proper low speed control on flat ground.

Parameter	Description
Seq chrg led	When set to On, cycles the battery status LEDs from the bottom segment to the top segment, with charge complete status indicated by flashing the top segment. Setting Seq chrg led to Off disables this feature. The display type used, determines how this option indicates a charge complete status.  An intelligent display with the ability to visually represent real time data is required to use Seq chrg led.
Save boost	When set to On , saves real-time motor compensation (boost) values and automatically reapplies them when stopping and restarting on an incline to prevent rollback. Boost values are not saved through a key switch power cycle.
Flash qstop	When set to On , while asserting a Quickstop, flashes the status LED on the controller at a constant 2Hz rate. If equipped with a display unit, also flashes the battery LEDs.
Fail dbstrt	When set to On or Off , it allows the status LED to display the appropriate error code.
Fail qstop	When set to On , with Quickstop asserted, allows the status LED to display the appropriate error code.
Serial throt	When set to On , configures the controller to respond to throttle from an Enhanced Deluxe Display.
Analog throt	When set to On , configures the controller to respond to an analog throttle directly connected to TPOTC input.
Sertht throt	When set to On , configures the controller to respond to the speed control pot from an Enhanced Deluxe Display as a throttle.
Invert sertht	When set to On while Sertht throt is enabled, inverts the operation of the response to the speed control.
Rollbck A	Speeds up the activation of the EM brake when stopping on an incline. It should be set low enough for acceptable stopping performance on a nominal incline, but should not be set so low that the brake prematurely engages when stopping on flat ground or grass.
Double pull	When set to On , makes it necessary to activate the throttle mechanism twice to make the vehicle drive.

Parameter	Description
In/Out cur	When turned On , uses the upper bound current limit setting when in Outdoor mode, and the lower bound current limit setting when in Indoor mode.
Shabat	Not supported by this Controller.
Full e2 sel	Not supported by this Controller.
Misc 1&2	Not supported by this Controller.
Misc 3&4	Not supported by this Controller.
Misc1 invert	Inverts the operation state of the Misc 1 input.
Misc2 invert	Inverts the operation state of the Misc 2 input.
Misc3 invert	Inverts the operation state of the Misc 3 input.
Misc4 invert	Inverts the operation state of the Misc 4 input.
Shutdown V	Voltage level of the battery, that when reached, shuts down the controller.
EMBrake V	Sets the desired EM brake voltage. The EM brake output is pulse width modulated to achieve values lower than the actual battery voltage. Output is independent of the battery voltage, but can never be higher than the absolute battery voltage.

Options Sub-Menu

Parameter	Description
RVS beep	When set to On , enables a horn beep (if equipped) when the controller is in reverse.
Uni rvs beep	When set to On , enables a horn beep (if equipped) when the controller is in reverse – for unidirectional throttle only.
Beep error	When set to On , Beep enables a horn beep (if equipped) when a controller error code is present. The horn will pulse out the error code, similar to the LED modulation for an error code.
Soft qstop	When set to On , asserting the quick stop input triggers a programmable softer stop. When set to Off , asserting quick stop triggers an abrupt stop.
Debug volts	When set to On , a sample battery voltage is displayed. This is used for battery related testing and problem diagnosis. Turn off when finished with diagnostics.
CHG to DRV	When set to On , the controller jumps to drive mode when charging completes. If enabled, the key must be on to jump to drive mode. When set to Off , the controller turns off when charging completes.
Diagnostics	When set to On , the controller performs general power-up self-diagnostics. Diagnostics are not performed when powering up in charge mode.
Brake diag	When set to On , electromagnetic (EM) brake diagnostics are enabled at power-up and also during operation. When set to Off , diagnostics are not performed on the EM brake output. Most applications with an EM brake require this option to be enabled as part of compliance standards.
Fast curlim	When set to On , the current limit characteristic of the controller will recover quickly in response to motor current, versus a slower cutback and recover.
Step curlim	When set to On , the current limit decay function changes to an abrupt step function, such that after a time defined by Cur time ; the current limit will drop from Cur lim hi to Cur lim lo . When set to Off , current limit will follow a normal linear decay function. See Figure 29.
Flsh chgstrt	When set to On , the status LED will flash when charging starts.

Parameter	Description
Fast chgled	A typical charging cycle will go through the following charging modes in order: 1. Pre-charge, 2. Charge Qualification, 3. Bulk Charge, 4. Top-off Charge, and 5. Float. The Fast chgled on/off setting determines when to flash the LED. When set to On, flash will occur at the end of Bulk Charge mode. When set to Off, flash will occur at the end of Top-off charge mode.
Moment key	When set to On , the system turns On and Off with a pushbutton or momentary contact of the key switch. When set to Off , the unit remains powered up only while the key switch remains closed, and powers down when the key switch contact is opened.
Timed key	When set to On , the unit will not power down immediately when key switch state indicates power down, but remains on for the duration defined by Timeout . When set to Off , the unit powers down as normal with no delays.
Accel drive	Used to configure throttle for acceleration control, instead of speed control. When set to Off , the controller interprets throttle as a conventional speed adjustment, where the direction and speed of the unit is determined by the displacement from center and the magnitude of the displacement. When set to On , a throttle displacement indicates acceleration to the controller. The unit accelerates proportional to this displacement, as long as it is present. Deceleration requires an equal and opposite displacement. FWD/REV input controls direction while Accel drive is On , which results in a hard stop when toggling direction.
Tht lmt bst	When set to On , motor compensation (boost) is limited by the absolute throttle position.
Acl lmt bst	When set to On , motor compensation (boost) is limited by the acceleration of the throttle position (change in throttle over time).
Soft decel	When set to On , negative (decelerating) boost is not applied, resulting in a soft deceleration.

Parameter	Description
Qstop hi	Depending on the module configuration quickstop can be wired as active (+5 V) or passive (GND). In a passive configuration: - When the parameter is On, quickstop is asserted when active. - When the parameter is Off, quickstop is asserted when the circuit is closed.
Indoor hi	When set to On , indoor input will be asserted on a high input instead of a low input.
Unidir thrt	When set to On , the full throttle displacement controls speed only, i.e. 0V to 5V (default forward), and direction is controlled by the FWD/RVS input. When set to Off , throttle displacement overrides the FWD/RVS input and controls speed and direction, i.e. 2.5V to 0V (default reverse) and 2.5V to 5V (default forward).
0V tht neut	When set to On , throttle neutral voltage will be 0V (typical 2-wire throttle, foot pedal control). When set to Off , throttle neutral voltage will be 2.5V (typical 3-wire throttle, wig-wag control).
AnIn throt	When set to On , the controller will respond to an analog max-speed control directly connected to the AnIn input. AnIn must be enabled.
MaxSpd thrt	When set to On , the controller will respond to a max-speed control on a Deluxe display.
Invert thrt	When set to On , throttle actuation is inverted such that a default forward actuation of the throttle results in reverse movement.

Functions Sub-Menu

Parameter	Description
Clr flt log	Clears all faults from the controller's Fault log.
Recall Init	Every time the HHP is powered up successfully, it stores the controller's current configuration. After changing various parameters, but before powering down the Hand-Held Programmer, this option can restore the controller's original configuration of all parameters. If the HHP power is turned off or lost, memory of the controller's configuration at the time of the last power-up is lost as well.
Recall Fact	Restores the factory default configuration of all parameters, if available (See Troubleshooting and Diagnostics on page 69 for details).
Save to Mem1	Stores the current configuration of all parameters to the Hand-Held Programmer's non-volatile memory. Overwrites any configuration currently stored. Values are not destroyed after recalling from memory to allow program-cloning of controllers. Values are only overwritten when Save to Mem1 is used again.  Use this feature cautiously when program-cloning, so as not to inadvertently program many controllers with undesired values.
Recall Mem1	Restores the Hand-Held Programmer's stored configuration of all parameters from Memory 1.
Save to Mem2	Functions the same as Save to Mem1 but stores to Mem2 .
Recall Mem2	Restores the Hand-Held Programmer's stored configuration of all parameters from Mem2 .
Save to Mem3	Functions the same as Save to Mem1 but stores to Mem3 .
Recall Mem3	Restores the Hand-Held Programmer's stored configuration of all parameters from Mem3 .
Save to Mem4	Functions the same as Save to Mem1 but stores to Mem4 .
Recall Mem4	Restores the Hand-Held Programmer's stored configuration of all parameters from Mem4 .
Save to Mem5	Functions the same as Save to Mem1 but stores to Mem5 .

Parameter	Description
Recall Mem5	Restores the Hand-Held Programmer's stored configuration of all parameters from Mem5 .
Save to Mem6	Functions the same as Save to Mem1 but stores to Mem6 .
Recall Mem6	Restores the Hand-Held Programmer's stored configuration of all parameters from Mem6 .
Save to Mem7	Functions the same as Save to Mem1 but stores to Mem7 .
Recall Mem7	Restores the Hand-Held Programmer's stored configuration of all parameters from Mem7 .

Debug Sub-Menu

Parameter	Description												
Fault Code	Displays the controller's current fault code, if present. Will display 00 if no fault present.												
Fault Log	Displays the controller's most recent fault log. To access the log: <table border="1"> <thead> <tr> <th>Step</th><th>Action</th></tr> </thead> <tbody> <tr> <td>1</td><td>On the HHP from the Main menu, scroll down to the Debug > menu parameter</td></tr> <tr> <td>2</td><td>Press > to enter the Debug menu</td></tr> <tr> <td>3</td><td>Scroll down to the Fault Log parameter</td></tr> <tr> <td>4</td><td>Press > to select the parameter</td></tr> <tr> <td>5</td><td>Press + to access the next fault, or – to access the previous fault</td></tr> </tbody> </table>  When a fault code is displayed, the > can be pushed to momentarily display the text associated with the error code. Up to 16 faults can be stored. FF or 00 represent a blank fault log location. Refer to the following URL: www.controls.com/index.php/support/troubleshoot/motor-controller for controller error code descriptions.	Step	Action	1	On the HHP from the Main menu, scroll down to the Debug > menu parameter	2	Press > to enter the Debug menu	3	Scroll down to the Fault Log parameter	4	Press > to select the parameter	5	Press + to access the next fault, or – to access the previous fault
Step	Action												
1	On the HHP from the Main menu, scroll down to the Debug > menu parameter												
2	Press > to enter the Debug menu												
3	Scroll down to the Fault Log parameter												
4	Press > to select the parameter												
5	Press + to access the next fault, or – to access the previous fault												
Product ID	Displays the controller's 4-digit CS product identification (e.g. CS1108 would display 1108).												
FW rev h	Displays the firmware revision of the controller.												
FW rev l	Displays the firmware revision of the controller.												
Serial # >	Displays the controller's serial number. To access the serial number: <table border="1"> <thead> <tr> <th>Step</th><th>Action</th></tr> </thead> <tbody> <tr> <td>1</td><td>On the HHP from the main menu, scroll down to the Debug > menu parameter</td></tr> <tr> <td>2</td><td>Press > to enter the Debug menu</td></tr> <tr> <td>3</td><td>Scroll down to the Serial # > parameter</td></tr> <tr> <td>4</td><td>Press > to select the parameter</td></tr> <tr> <td>5</td><td>Press < to return to the Debug menu</td></tr> </tbody> </table>	Step	Action	1	On the HHP from the main menu, scroll down to the Debug > menu parameter	2	Press > to enter the Debug menu	3	Scroll down to the Serial # > parameter	4	Press > to select the parameter	5	Press < to return to the Debug menu
Step	Action												
1	On the HHP from the main menu, scroll down to the Debug > menu parameter												
2	Press > to enter the Debug menu												
3	Scroll down to the Serial # > parameter												
4	Press > to select the parameter												
5	Press < to return to the Debug menu												
PWM	Displays in real time, the set PWM duty cycle percent of the drive system output (M1+/M1- motor terminals).												
Speed	Displays in real time the speed percentage that the controller attempts to maintain.												

Parameter	Description																																
Throt V	Displays in real time, the throttle input voltage in volts. There is a two place decimal point that is not displayed on the programmer, so a displayed value of 0100 would equal 1.00V , and a displayed value of 0250 would equal 2.50V .																																
Throt val	Displays in real time the absolute throttle percentage from neutral with respect to the throttle input range.																																
Throt center	Displays in real time when the throttle is in the center position.																																
Throt fault	Displays in real time when there is a throttle fault.																																
Short ckt	Displays in real time if there is a short circuit in the throttle circuit.																																
Off push	Displays in real time, On if the vehicle is being pushed while the key is off and charging mode is off.																																
Max speed	Displays in real time, the set maximum speed percentage, which can be set by an intelligent display (CS1151A, CS1161). Check Throt flags to see which input is used to set Maximum Speed.																																
Analog in	Displays in real time, the Analog input voltage, relative to the controller's +5V power supply, in terms of percentage.																																
Throt flags	Displays different throttle and max speed option configurations. Enabled = 1, Disabled = 0. They are defined as follows: <table><tr><th>No.</th><th>Option(s)</th><th>Hex Code</th><th>Description</th></tr><tr><td>1</td><td>Inverted Throttle</td><td>01</td><td>Changes the driving throttle actuation so that a normal forward actuation of the throttle results in reverse operation from the controller</td></tr><tr><td>2</td><td>Max Speed = Analog Input</td><td>04</td><td>Enables analog input to be used for max speed control</td></tr><tr><td>3</td><td>Max Speed = Max Speed</td><td>10</td><td>Enables max speed input to be used for max speed control</td></tr><tr><td>4</td><td>Max Speed = Serial throt</td><td>40</td><td>Enables Serial throt input to be used for max speed control</td></tr><tr><td>5</td><td>1 & 2</td><td>05</td><td>(See 1 & 2 above)</td></tr><tr><td>6</td><td>1 & 3</td><td>11</td><td>(See 1 & 3 above)</td></tr><tr><td>7</td><td>1 & 4</td><td>41</td><td>(See 1 & 4 above)</td></tr></table>	No.	Option(s)	Hex Code	Description	1	Inverted Throttle	01	Changes the driving throttle actuation so that a normal forward actuation of the throttle results in reverse operation from the controller	2	Max Speed = Analog Input	04	Enables analog input to be used for max speed control	3	Max Speed = Max Speed	10	Enables max speed input to be used for max speed control	4	Max Speed = Serial throt	40	Enables Serial throt input to be used for max speed control	5	1 & 2	05	(See 1 & 2 above)	6	1 & 3	11	(See 1 & 3 above)	7	1 & 4	41	(See 1 & 4 above)
No.	Option(s)	Hex Code	Description																														
1	Inverted Throttle	01	Changes the driving throttle actuation so that a normal forward actuation of the throttle results in reverse operation from the controller																														
2	Max Speed = Analog Input	04	Enables analog input to be used for max speed control																														
3	Max Speed = Max Speed	10	Enables max speed input to be used for max speed control																														
4	Max Speed = Serial throt	40	Enables Serial throt input to be used for max speed control																														
5	1 & 2	05	(See 1 & 2 above)																														
6	1 & 3	11	(See 1 & 3 above)																														
7	1 & 4	41	(See 1 & 4 above)																														

Parameter	Description																																
Battery V	If Debug volts is enabled, Battery V displays in real time the battery voltage. Otherwise, it displays the battery capacity. There is a two place decimal point that is not displayed on the programmer, so a displayed value of 0100 would equal 1.00V , and a displayed value of 0250 would equal 2.50V .																																
Temp	Displays in real time, the temperature of the drive FET transistors.																																
Current A	Displays in real time, the motor current in Amps.																																
Buttons	Each one of the eight bits that make up the hexadecimal value represents one button on a deluxe display. A button pressed = 0, not pressed = 1. They are defined as follows: <table><tr><td>Bit 8</td><td>Bit 7</td><td>Bit 6</td><td>Bit 5</td><td>Bit 4</td><td>Bit 3</td><td>Bit 2</td><td>Bit 1</td></tr><tr><td>Break Release</td><td>Seat Up</td><td>Head light</td><td>Seat Down</td><td>Right Turn Signal</td><td>Speed Up</td><td>Left Turn Signal</td><td>Speed Down</td></tr></table> If only one button is pressed at a time, the hexadecimal codes displayed will be as follows: <table><tr><td>Break Release</td><td>Seat Up</td><td>Head light</td><td>Seat Down</td><td>Right Turn Signal</td><td>Speed Up</td><td>Left Turn Signal</td><td>Speed Down</td></tr><tr><td>7F</td><td>BF</td><td>DF</td><td>EF</td><td>7F</td><td>FB</td><td>FD</td><td>FE</td></tr></table> If more than one button is pressed at a time, a combination of bits will be 0 at the same time. There are 255 possible combinations. This feature can be helpful to determine which button(s) may be stuck down on a deluxe display e.g. FF = no buttons pressed, FE = Speed Down, FC = Speed Down and Left Turn Signal, 00 = All Buttons presses.	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Break Release	Seat Up	Head light	Seat Down	Right Turn Signal	Speed Up	Left Turn Signal	Speed Down	Break Release	Seat Up	Head light	Seat Down	Right Turn Signal	Speed Up	Left Turn Signal	Speed Down	7F	BF	DF	EF	7F	FB	FD	FE
Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1																										
Break Release	Seat Up	Head light	Seat Down	Right Turn Signal	Speed Up	Left Turn Signal	Speed Down																										
Break Release	Seat Up	Head light	Seat Down	Right Turn Signal	Speed Up	Left Turn Signal	Speed Down																										
7F	BF	DF	EF	7F	FB	FD	FE																										
Indoor pin	Displays in real time whether the Indoor mode (drive mode 2) is on or off.																																
Indoor mode	Displays in real time, On when in Indoor mode (drive mode 2).																																
QStop pin	Displays in real time, if the controller is seeing a quick stop input.																																
Quick stop	Shows On when Quick Stop is active.																																
Brk rel pin	Displays in real time, On when the controller sees a high external brake release input.																																
Brake rel	Displays in real time, On when Brake Release is active.																																

Parameter	Description																																				
Charging	Displays in real time, On when Charge Mode is active.																																				
Keyswitch	Displays in real time whether the controller detects a key switch.																																				
Reverse pin	Displays On when the controller detects an active reverse input.																																				
Reverse	Displays On when the Reverse input is active.																																				
Chrg time	Displays elapsed time for the current Charging Mode. Time resets for every Charging Mode change. For Charging Time in hours and minutes, convert from hexadecimal using Figure 30. Hours:Minutes <table><thead><tr><th>Hexadecimal</th><th>Hours:Minutes</th></tr></thead><tbody><tr><td>0000</td><td>0:00</td></tr><tr><td>1000</td><td>2:17</td></tr><tr><td>2000</td><td>4:33</td></tr><tr><td>3000</td><td>6:50</td></tr><tr><td>4000</td><td>9:06</td></tr><tr><td>5000</td><td>11:23</td></tr><tr><td>6000</td><td>13:39</td></tr><tr><td>7000</td><td>15:56</td></tr><tr><td>8000</td><td>18:12</td></tr><tr><td>9000</td><td>20:29</td></tr><tr><td>A000</td><td>22:45</td></tr><tr><td>B000</td><td>25:02</td></tr><tr><td>C000</td><td>27:18</td></tr><tr><td>D000</td><td>29:35</td></tr><tr><td>E000</td><td>31:51</td></tr><tr><td>F000</td><td>34:08</td></tr><tr><td>FFFF</td><td>36:24</td></tr></tbody></table> Hexadecimal	Hexadecimal	Hours:Minutes	0000	0:00	1000	2:17	2000	4:33	3000	6:50	4000	9:06	5000	11:23	6000	13:39	7000	15:56	8000	18:12	9000	20:29	A000	22:45	B000	25:02	C000	27:18	D000	29:35	E000	31:51	F000	34:08	FFFF	36:24
Hexadecimal	Hours:Minutes																																				
0000	0:00																																				
1000	2:17																																				
2000	4:33																																				
3000	6:50																																				
4000	9:06																																				
5000	11:23																																				
6000	13:39																																				
7000	15:56																																				
8000	18:12																																				
9000	20:29																																				
A000	22:45																																				
B000	25:02																																				
C000	27:18																																				
D000	29:35																																				
E000	31:51																																				
F000	34:08																																				
FFFF	36:24																																				
Charge mode	Indicates current mode of operation while charging. Codes are as follows: 00 = Pre-charge, 02 = Charge qualification/Bulk charge, 04 = Top-Off charge, and 08 = Float charge.																																				

Figure 30 - Charging Time Conversion

This page intentionally left blank

Parameter Information

Table 11 - Table 17 provide a listing of the HHP parameters and their read/write (R/W) capability, range, unit of measure and whether the parameter is dynamic. The last column of each table indicates whether the parameter can be modified by the OEM HHP, Dealer HHP, or both. The column key for HHP is:

O = OEM only

B = OEM and Dealer

Main Menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
FAULT CODE!	Read only	00-FF	Hex	Y	B
FWD speed	Y	0-100	%	N	B
RVS speed	Y	0-100	%	N	B
Min speed	Y	0-100	%	N	O
FWD accel	Y	0-100	%	N	B
FWD decel	Y	0-100	%	N	B
FWD>RVSdcl	Y	0-100	%	N	B
RVS accel	Y	0-100	%	N	B
RVS decel	Y	0-100	%	N	B
RVS>FWDdcl	Y	0-100	%	N	B
Motor comp	Y	0-240	Decimal	N	B
Indoor mode >	—	—	—	—	B
Throtl scl	Y	0-255	Decimal	N	O
Deadband	Y	0-255	Decimal	N	O
Failband	Y	0-255	Decimal	N	O
Push speed	Y	0-100	%	N	O
Hold time	Y	0-100	%	N	O
Ramp shape	Y	0-15	—	N	O
Comp rspns	Y	0-100	%	N	O
Brake time	Y	0.00-2.55	Seconds	N	B
Keyoff dcl	Y	0-100	%	N	O
Batt res	Y	0-255	[†] Coefficient	N	O
Timeout	Y	0-240	Minutes	N	B
Flash V	Y	18-23	Volts	N	B
Full V	Y	23.1-26	Volts	N	B
[†] Note: Refer to the parameter description on page 45					

Main Menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
Cur lim lo	Y	1.2-292.5	Amps	N	O
Cur lim hi	Y	1.2-292.5	Amps	N	O
Cur time	Y	1-253	—	N	O
Meters >	—	—	—	—	B
Advanced >	—	—	—	—	O
Options >	—	—	—	—	B
Functions >	—	—	—	—	B
Debug >	—	—	—	—	B
HHP Cntrst	Y	0-100	%	N	B

Table 11 - HHP Main Menu Parameter Reference

Indoor Mode Sub-menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
In FWD spd	Y	0-100	%	N	B
In RVS spd	Y	0-100	%	N	B
In FWD acl	Y	0-100	%	N	B
In FWD dcl	Y	0-100	%	N	B
In FWD dch	Y	0-100	%	N	B
In RVS acl	Y	0-100	%	N	B
In RVS dcl	Y	0-100	%	N	B
In RVS dch	Y	0-100	%	N	B
In mot cmp	Y	0-240	Decimal	N	B

Table 12 - HHP Indoor Mode Sub-menu Parameter Reference

Meters Sub-menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
Hours	Read only	0-65535.9	Hours	Y	B
Low Batt	Read only	0-255:59	Hours:Minutes	Y	B
Overtmps	Read only	0-255	Decimal	Y	B
Tht Faults	Read only	0-255	Decimal	Y	B
Chg Nofloats	Read only	0-255	Decimal	Y	B
Note: Counters and timers do not roll over or reset.					

Table 13 - HHP Meters Sub-menu Parameter Reference

Advanced Sub-menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
Fwd Plg Tm	Y	0.00-10.20	Seconds	N	O
Rvs Plg Tm	Y	0.00-10.20	Seconds	N	O
Regen off	Y	On/off	–	N	O
Idle push	Y	On/off	–	N	O
Creep spd	Y	0-100	%	N	O
In CRP spd	Y	0-100	%	N	O
Seq chrg led	Y	On/off	–	N	O
Save boost	Y	On/off	–	N	O
Flash qstop	Y	On/off	–	N	O
Fail dbstrt	Y	On/off	–	N	O
Fail qstop	Y	On/off	–	N	O
Serial throt	Y	On/off	–	N	O
Analog throt	Y	On/off	–	N	O
Sertht throt	Y	On/off	–	N	O
Invert sertht	Y	On/off	–	N	O
Rollbck A	Y	0.0-621.7	Amps	N	O
Double pull	Y	On/off	–	N	O
In/Out cur	Y	On/off	–	N	O
Shabat	Y	On/off	–	N	O
Full e2 sel	Y	On/off	–	N	O
Misc 1&2	Y	00-FF	Hex	N	O
Misc 3&4	Y	00-FF	Hex	N	O
Misc1 invert	Y	On/off	–	N	O
Misc2 invert	Y	On/off	–	N	O
Misc3 invert	Y	On/off	–	N	O
Misc4 invert	Y	On/off	–	N	O
Shutdown V	Y	3.58-29.94	Volts	N	O
EMBrake V	Y	0-45.72	Volts	N	O

Table 14 - HHP Advanced Sub-menu Parameter Reference

Options Sub-menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
RVS beep	Y	On/off	–	N	B
Uni rvs beep	Y	On/off	–	N	O
Beep error	Y	On/off	–	N	O
Soft qstop	Y	On/off	–	N	O
Debug volts	Y	On/off	–	N	B
CHG to DRV	Y	On/off	–	N	O
Diagnostics	Y	On/off	–	N	O
Brake diag	Y	On/off	–	N	O
Fast curlim	Y	On/off	–	N	O
Step curlim	Y	On/off	–	N	O
Flsh chgstrt	Y	On/off	–	N	O
Fast chgled	Y	On/off	–	N	O
Moment key	Y	On/off	–	N	O
Timed key	Y	On/off	–	N	O
Accel drive	Y	On/off	–	N	O
Tht lmt bst	Y	On/off	–	N	O
Acl lmt bst	Y	On/off	–	N	O
Soft decel	Y	On/off	–	N	O
Qstop hi	Y	On/off	–	N	O
Indoor hi	Y	On/off	–	N	O
Unidir thrt	Y	On/off	–	N	O
0V tht neut	Y	On/off	–	N	O
AnIn throt	Y	On/off	–	N	O
MaxSpd thrt	Y	On/off	–	N	O
Invert thrt	Y	On/off	–	N	O

Table 15 - HHP Options Sub-menu Parameter Reference

Functions Sub-menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
Clr flt log	Y	Y/N	–	N	B
Recall Init	Y	Y/N	–	N	B
Recall Fact	Y	Y/N	–	N	B
Save to Mem1	Y	Y/N	–	N	B
Recall Mem1	Y	Y/N	–	N	B
Save to Mem2	Y	Y/N	–	N	B
Recall Mem2	Y	Y/N	–	N	B
Save to Mem3	Y	Y/N	–	N	B
Recall Mem3	Y	Y/N	–	N	B
Save to Mem4	Y	Y/N	–	N	B
Recall Mem4	Y	Y/N	–	N	B
Save to Mem5	Y	Y/N	–	N	B
Recall Mem5	Y	Y/N	–	N	B
Save to Mem6	Y	Y/N	–	N	B
Recall Mem6	Y	Y/N	–	N	B
Save to Mem7	Y	Y/N	–	N	B
Recall Mem7	Y	Y/N	–	N	B

Table 16 - HHP Functions Sub-menu Parameter Reference

Debug Sub-menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
Fault Code	Read only	00-FF	Hex	N	B
Fault Log	Read only	00-FF	Hex	N	B
Product ID	Read only	–	–	N	B
FW rev h	Read only	00-FF	Hex	N	B
FW rev l	Read only	00-FF	Hex	N	B
Serial # >	Read only	–	–	N	B
PWM	Read only	0-100	%	Y	*B
Speed	Read only	0-100	%	Y	O
Throt V	Read only	0-5	Volts	Y	B
Throt val	Read only	0-100	%	Y	B
Throt center	Read only	On/off	–	Y	B
Throt fault	Read only	On/off	–	Y	B
* Note: Different order to menu items					

Debug Sub-menu					
Parameter	R/W	Range	Measure	Dynamic	HHP
Short ckt	Read only	On/off	—	Y	O
Off push	Read only	On/off	—	Y	O
Max speed	Y	0-100	%	Y	B
Analog in	Read only	0-100	%	Y	B
Throt flags	Read only	*00-FF	Hex	Y	B
Battery V	Read only	0-99	Volts	Y	B
Temp	Read only	-20 to +147	°C	Y	B
Current A	Read only	-999.9 to +999.9	Amps	Y	B
Buttons	Read only	00-FF	Hex	Y	B
Indoor pin	Read only	On/off	—	Y	B
Indoor mode	Read only	On/off	—	Y	B
QStop pin	Read only	On/off	—	Y	O
Quick stop	Read only	On/off	—	Y	B
Brk rel pin	Read only	On/off	—	Y	O
Brake rel	Read only	On/off	—	Y	B
Charging	Read only	On/off	—	Y	B
Keyswitch	Read only	On/off	—	Y	O
Reverse pin	Read only	On/off	—	Y	O
Reverse	Read only	On/off	—	Y	B
Chrg time	Read only	0000-FFFF	Hex	Y	B
Charge mode	Read only	00-08	Hex	Y	B
*Note: Bit mapped					

Table 17 - HHP Debug Sub-menu Parameter Reference

Troubleshooting and Diagnostics

This section provides references to the latest troubleshooting and error code information for the CS1108 PWM Motor Controller and the CS1171 Hand-Held Programmer.

The most current information is always available from the Control Solutions website. Table 18 provides direct links to the web pages for the CS1108 LED Error Codes, CS1171 Error Displays and related troubleshooting information.

Product	Website URL
Motor Controller	http://www.controls.com/index.php/support/troubleshoot/motor-controller
Hand-Held Programmer	http://www.controls.com/index.php/support/troubleshoot/hhp

Table 18 - Troubleshooting URLs

This page intentionally left blank

Contacting Customer Service

Customer Service is a top priority at Control Solutions. We are committed to being a leader in our industries, while providing our customers with superior quality, value, and service. We are here to help you find answers to your Control Solutions LLC related questions.

If you have any questions, experience technical problems, need any parts or service, contact Control Solutions LLC Customer Service during normal business hours (Mon-Fri, 8am-5pm Central Time) at (630) 806-7062.

This page intentionally left blank

Parameter Setting Worksheet

Use the following worksheet to document your parameter values.

Parameter	Value	Parameter	Value	Parameter	Value
Main Menu	—	In FWD acl		Misc2 invert	
FWD speed		In FWD dcl		Misc3 invert	
RVS speed		In FWD dch		Misc4 invert	
Min speed		In RVS acl		Shutdown V	
FWD accel		In RVS dcl		EMBrake V	
FWD decel		In RVS dch		Options Menu	—
FWD>RVSdcl		In mot cmp		RVS beep	
RVS accel		Advanced Menu	—	Uni rvs beep	
RVS decel		Fwd Plg Tm		Beep error	
RVS>FWDdcl		Rvs Plg Tm		Soft qstop	
Motor comp		Regen off		Debug volts	
Throtl scl		Idle push		CHG to DRV	
Deadband		Creep spd		Diagnostics	
Failband		In CRP spd		Brake diag	
Push speed		Seq chrg led		Fast curlim	
Hold time		Save boost		Step curlim	
Ramp shape		Flash qstop		Fish chrgstrt	
Comp rspns		Fail dbstrt		Fast chgled	
Brake time		Fail qstop		Moment key	
Keyoff dcl		Serial throt		Timed key	
Batt res		Analog throt		Accel drive	
Timeout		Sertht throt		Tht lmt bst	
Flash V		Invert sertht		Acl lmt bst	
Full V		Rollbck A		Soft decel	
Cur lim lo		Double pull		Qstop hi	
Cur lim hi		In/Out cur		Indoor hi	
Cur time		Shabat		Unidir thrt	
HHP Cntrst		Full e2 sel		0V tht neut	
Indoor Menu	—	Misc 1&2		AnIn throt	
In FWD spd		Misc 3&4		MaxSpd thrt	
In RVS spd		Misc1 invert		Invert thrt	

This page intentionally left blank

Appendix A

Note: The connector orientation matches their appearance on the motor controller with the connectors at the top of the motor controller and the connector tabs at the top when looking into the connector

JP1

Pin	Name
1	Protected Battery +
2	Battery -
3	Key Switch
4	Clock
5	Data
6	Per Low
7	Per Wiper
8	Per High

J7

Pin	Name
1	Battery -
2	Battery +
3	Per High
4	Per Wiper
5	Key Switch
6	Break
7	See Note 1
8	See Note 2
9	LED
10	Battery +
11	See Note 2
12	Quick Stop
13	Per Low
14	ESB+
15	Data
16	Room
17	FWD/REV
18	AMIN

Battery

Pin	Name
J1	Battery -
J2	Battery +
J8	Battery -
J9	Battery -

JP2

Pin	Name
1	Charge Comm
2	Drive Inhibit
3	Batt -
4	Batt +

Motor

Pin	Name
J3	Motor -
J4	Motor -
J5	Motor +
J6	Motor +

JP1

8 ← 1

Pins

J7

18 17 16 15 14 13 12 11 10

9 8 7 6 5 4 3 2 1

Battery

(J1) Batt - (J2) Batt + (J8) Batt - (J9) Batt +

JP2

4 3 2 1

Motor

(J3) (J4) (J5) (J6)

M1- M1+ M1- M1+

CS1108P - V2.0.8
3S VDC Motor Controller
© 2007 Control Solutions, Inc. 07-2007

Notes

- 1 Clock - can be used as Break Release - contact CSLLC for details
- 2 PCB 1209D Battery + PCB 1209F RAINW24/H PCB 1209G RAINW24/H PCB 5851A RAINW24/H (protected battery+)

Connector **Part Number** **Mating Part**

JP1	Tyco 596416-1	Tyco 5-554735-3
JP2	Molex 36-28-1043	Molex 36-01-2040
J7	Molex 36-28-1183	Molex 36-01-2180
J1 and J8	Zenick 6041	Tyco 908522-1
J2 and J9	Zenick 6041	Tyco 908522-1
J3 - J6	Zenick 6041	Tyco 160351-2

Page 75 of 76

Control Solutions LLC

Designed &
Manufactured



In the USA



Registered to
ISO 9001



CONTROL SOLUTIONS LLC
INNOVATIVE SOLUTIONS FOR A WORLD IN MOTION

WWW.CONTROLS.COM

2520 DIEHL ROAD • AURORA, ILLINOIS 60502 • PHONE: (630) 806-7062 • FAX: (630) 806-7065